

# Map Sensors

*by Eric Blythe*

Always mount your Map Sensor with the vacuum tube pointing downwards. This ensures that any moisture build up will drain from the unit and save you a costly replacement.